



Stream Habitat Assessment Procedure

(Adapted from *Volunteer Stream Monitoring: A Methods Manual, United States Environmental Protection Agency, Office of Water, Draft Document #EPA 841-B-97-003, November 1997.*)

Each time you conduct macroinvertebrate sampling you will also assess the stream habitat for fish, macroinvertebrates, and plants. Just as with macroinvertebrate sampling the type of stream habitat - rocky bottom versus muddy bottom - affects your assessment procedures.

Rocky Bottom Habitats

Conduct the habitat assessment twice a year, in the spring and in the fall, at the site that you used for your macroinvertebrate sampling.

- 1. Attachment sites for macroinvertebrates** are essentially the amount of living space or hard substrates (rocks, snags, etc.) available for aquatic insects and snails. Many insects begin their life underwater in streams and need to attach themselves to rocks, logs, branches, or other sub-merged substrates. In streams unimpaired by pollution, the greater the variety and number of available living spaces or attachment sites, the greater the variety of insects the stream habitat could support. Optimally, cobble should predominate and boulders and gravel should be common. The availability of suitable living spaces for macroinvertebrates decreases as cobble becomes less abundant and boulders, gravel, or bedrock become more prevalent.
- 2. Embeddedness** refers to the extent that rocks (gravel, cobble, and boulders) are surrounded by, covered, or sunken into the silt, sand, or mud of the stream bottom. As rocks become embedded, fewer living spaces are available to macroinvertebrates and fish for shelter, spawning and egg incubation. To estimate the percent of embeddedness, observe the amount of silt or finer sediments overlying and surrounding the rocks. If kicking does not dislodge the rocks or cobbles, they might be greatly embedded.
- 3. Shelter for fish** and macroinvertebrates includes the relative quantity and variety of natural structures in the stream, such as fallen trees, logs, and branches; root wads; large cobble and boulders; and undercut banks that are available to fish for hiding, sleeping, or feeding. A wide variety of submerged structures means more living spaces in a stream and the more types of fish and other aquatic life the stream can support. **Assess the stream as far as you can see.**
- 4. Channel alteration** is a measure of large-scale changes in the shape of the stream channel. Many streams in urban and agricultural areas have been straightened, deepened, dredged, or diverted into concrete channels, often for flood control purposes. Such streams have far fewer natural habitats for fish, macroinvertebrates, and plants than do naturally meandering streams. Channel alteration is present when the stream runs through a concrete channel; when artificial embankments, riprap, and other forms of artificial bank stabilization or structures are present; when the stream is very straight for significant distances; when dams, bridges, and flow-altering structures such as stormwater pipes are present; when the stream is



of uniform depth due to dredging; and when other such changes have occurred. Signs that indicate the occurrence of dredging include straightened, deepened, and otherwise uniform stream channels, as well as the removal of streamside vegetation to provide dredging equipment access to the stream. **Assess channel alteration up and down the stream as far as you can see.**

5. **Sediment deposition** is a measure of the amount of sediment that has been deposited in the stream channel and the changes to the stream bottom that have occurred as a result of the deposition. High levels of sediment deposition create an unstable and continually changing environment that is unsuitable for many aquatic organisms. Sediments are naturally deposited in areas where the stream flow is reduced, such as pools and bends, or where flow is obstructed. These deposits can lead to the formation of islands, shoals, or point bars (sediments that build up in the stream, usually at the beginning of a meander) or can result in the complete filling of pools. To determine whether sediment deposits are new, look for vegetation growing on them: new sediments will not yet have been colonized by vegetation.
6. **Stream velocity and depth combinations** are important to the maintenance of healthy aquatic communities. Fast water increases the amount of dissolved oxygen in the water, keeps pools from being filled with sediment, and helps food items like leaves, twigs, and algae move more quickly through the aquatic system. Slow water provides spawning areas for fish and shelters macroinvertebrates that might be washed downstream in high stream velocities. Similarly, shallow water tends to be more easily aerated (i.e. holds more oxygen), but deeper water stays cooler longer. Thus the best stream habitat includes all of the following velocity/depth combinations and can maintain a wide variety of organisms.
 - * slow (<1 ft/sec or <0.3048 m/sec), shallow (0.4572 m or <1.5 ft)
 - * fast, deep
 - * slow, deep
 - * fast, shallow
7. **Channel flow status** is the percentage of the existing channel that is filled with water. The flow status changes as the channel enlarges or as flow decreases as a result of dams and other obstructions, diversions for irrigation, or drought. When water does not cover much of the streambed, the living area for aquatic organisms is limited.

For the next three parameters, evaluate the condition of the right and left stream banks separately. Define the “left” and “right” banks by standing at the downstream end of your study stretch and looking upstream. Each bank is evaluated on a scale of 0-10.

8. **Bank vegetative protection** measures the amount of the stream bank that is covered by vegetation. The root systems of plants growing on stream banks help hold soil in place, reducing erosion. Vegetation on banks provides shade for fish and macroinvertebrates and serves as a food source by dropping leaves and other organic matter into the stream. Ideally, a variety of vegetation should be present, including trees, shrubs, and grasses. Vegetative disruption can occur when the grasses and plants on the stream banks are mowed or grazed, or when the trees and shrubs are cut back or cleared.



9. **Condition of banks** measures erosion potential and whether the stream banks are eroded. Steep banks are more likely to collapse and suffer from erosion than are gently sloping banks and are therefore considered to have a high erosion potential. Signs of erosion include crumbling, unvegetated banks, exposed tree roots, and exposed soils.
10. **The riparian vegetative zone width** is defined as the width of vegetation from the edge of the stream bank. The riparian vegetative zone is a buffer to prevent pollutants from entering a stream. It also controls erosion and provides stream habitat and nutrient input to the stream. A wide, relatively undisturbed riparian vegetative zone helps maintain a healthy stream system; narrow, far less useful riparian zones occur when roads, parking lots, fields, lawns, and other cultivated areas, bare soil, rocks or buildings are near the stream bank. The presence of “old fields” (i.e. previously developed agricultural fields allowed to revert to natural conditions) should be rated higher than fields in continuous or periodic use. In arid areas, the riparian vegetative zone can be measured by observing the width of the area dominated by riparian or water-loving plants, such as willows, marsh grasses, and cotton wood trees.



Stream Habitat Assessment Procedure

(Adapted from Volunteer Stream Monitoring: A Methods Manual, United States Environmental Protection Agency, Office of Water, Draft Document #EPA 841-B-97-003, November 1997.)

Each time you conduct macroinvertebrate sampling you will also assess the stream habitat for fish, macroinvertebrates, and plants. Just as with macroinvertebrate sampling the type of stream habitat - rocky bottom versus muddy bottom - affects your assessment procedures.

Muddy Bottom Habitats

Conduct the habitat assessment twice a year, in the spring and in the fall, at the site you used for your macroinvertebrate sampling.

- 1. Shelter for fish and attachment sites for macroinvertebrates** are the amount of living space and shelter (rocks, snags, and undercut banks) available for fish, insects, and snails. Many insects attach themselves to rocks, logs, branches, or other submerged substrates. Fish can hide or feed in these areas. The greater the variety and number of available shelter sites or attachment sites, the greater the variety of fish and insects in the stream. Many of the attachment sites result from debris falling into the stream from the surrounding vegetation. When debris first falls into the water, it is termed “new fall” and it has not yet been “broken down” or conditioned by microbes for macroinvertebrate colonization. Leaf material or debris that is conditioned is called “old fall.” Leaves that have been in the stream for some time turn brown or dull yellow, becomes blackened or dark in color; smooth bark become coarse and partially disintegrated, creating holes and crevices. It might also be slimy to the touch.
- 2. Pool substrate characterization** evaluates the type and condition of bottom substrates found in pools. Pools with firmer sediment types (e.g. gravel, sand) and rooted aquatic plants support a wider variety of organisms than do pools with substrates dominated by mud or bedrock and no plants. In addition, a pool with one uniform substrate type will support far fewer types of organisms than will a pool with a wide variety of substrate types.
- 3. Pool variability** rates the overall mixture of pool types found in the stream according to size and depth. The four basic types of pools are large-shallow, large-deep, small-shallow, and small-deep. A stream with many pool types will support a wide variety of aquatic species. Rivers with low sinuosity (few bends) and monotonous pool characteristics do not have sufficient quantities and types of habitats to support a diverse aquatic community.
- 4. Channel alteration** (see description in habitat assessment for rocky bottom streams.)
- 5. Sediment deposition** (see description in habitat assessment for rocky bottom streams.)
- 6. Channel sinuosity** evaluates the sinuosity or meandering of the stream. Streams that meander provide a variety of habitats (such as pools and runs) and stream velocities that reduce the energy from current surges during storm events. Straight stream segments are characterized by even stream depth and unvarying velocity, and they are prone to flooding.



To evaluate this parameter, imagine how much longer the stream would be if it were straightened out.

7. **Channel flow status** (see description in habitat assessment for rocky bottom streams)
8. **Bank vegetative protection** (see description in habitat assessment for rocky bottom streams)
9. **Condition of banks** (see description in habitat assessment for rocky bottom streams)
10. **The riparian vegetative zone width** (see description in habitat assessment for rocky bottom streams)